




CERATO

- **Workshop Manual Cerato Option
Smart Key Components Replacement**

CERRM2H/2/1



www.cargeek.ir

Specification

IPM (Smart Key Unit)

Items	Specification
Rated voltage	DC 12V
Operating voltage	DC 9 ~ 16V
Operating temperature	-30°C ~ 75°C (-22°F ~ 167°F)
Load	Max. 2mA

RF Receiver

Items	Specification
Frequency	433.92 MHz
Antenna type	FSK (Frequency Shift Keying)


Smart Key FOB

Items	Specification
Battery	Lithium battery 3V 1EA
Distance	10m
Battery life	More than 2years
Push buttons	Door lock / unlock / Trunk / Panic
Frequency(Rx)	125 kHz
Frequency(Tx)	433.92 MHz
Numbers	2EA


Antenna

Items	Specification
Rated voltage	DC 12V
Operating voltage	DC 9 ~ 16V
Operating temperature	-30°C ~ 75°C (-22°F ~ 167°F)
Frequency	125kHz
Numbers	Interior(3EA), Door(2EA), Bumper(1EA)

Component Location (1)



Component Location (2)



Description

The SMART KEY system is a system that allows the user to access and operate a vehicle in a very convenient way. To access the vehicle, no traditional key or remote control unit is needed.

The user carries a SMART KEY FOB which does not require any conscious actions by the user (e.g. operate a RKE button). The SMART KEY system is triggered by pressing a push button in the door handle.

After being triggered the vehicle sends out a request in a limited range. If the SMART KEY FOB receives this request, it automatically sends a response to the vehicle. Then the system decides whether to perform a particular action (unlocking, locking...) or remain inactive.

In a similar manner the vehicle's Electrical Steering Column Lock (ESCL) is released. Again, a communication between the vehicle and the SMART KEY FOB is needed before any actions will be performed.

The System offers the following features :

- passive unlock via door driver side and passenger side
- passive locking via door driver side and passenger side
- passive start
- passive access trunk/tailgate via the trunk lid switch at the trunk
- passive locking via tailgate
- max. 2 fobs can be handled by the system
- immobilizer backup antenna driver integrated into FOB-HOLDER for TP authentication (i.e. limp home mode)
- communication with engine management system
- communication with SRX
- LF-RF communication

1. Passive unlock

The system allows the user to access (unlock) the vehicle without performing any actions with the SMART KEY FOB.

This feature could be different depending on platform as follows:

A. Pressing Push button in door handle

2. Passive locking

The system allows the user to lock the vehicle by pushing a button on door handle with the SMART KEY FOB.

3. Button start

The system allows the user to release ESCL and to switch the power modes (Off, Accessory, Ignition), as well as to start and stop the vehicle's engine without performing any actions with the SMART KEY FOB. See Button Engine Start system specification.

4. LIMP HOME Mode

Additionally, the system offers so called "limp home mode", which is the user can operate all vehicle functions by inserting the key into the FOB HOLDER.

Smart Key ECU (SMK ECU)

The SMK ECU manages all functions related to "Passive Unlock", "Passive Lock" and "Passive Authorization for Engine Start Operation".

It reads the inputs (Push button in door handle, Start Stop Button (SSB), PARK position Switch), controls the outputs (e.g. exterior and interior antennas), and communicates via the CAN/LIN (depends on the vehicle) as well as a single line interface to further devices of the car.

It reads the inputs (Push button in door handle, Start Stop Button (SSB), PARK position Switch), controls the outputs (e.g. exterior and interior antennas), and communicates via the CAN as well as a single line interface to further devices of the car.

For communication with the SMART KEY FOB, SMK ECU generates a request (challenge) as an encoded and modulated 125 kHz signal at the inductive antenna outputs and receives the SMART KEY FOB's response via the external RF receiver.

The main functional blocks of the SMK ECU are:

- Power supply
- Microcontroller with FLASH Memory
- Single Line Interface to SRX
- Single Line Interface to EMS

- Input stage
- LF antenna amplifier/driver
- CAN communication with BCM
- LIN communication with other unit (depending on platform)

The LF antenna amplifier/driver generates a 125 kHz sinusoidal carrier signal which is distributed to the different antennas.

Smart Key FOB

The system supports up to 2 SMART KEY FOBs.

The main functions of the SMART KEY FOB are:

- Passive functionality: receives LF-challenge and sends automatically RF response.
- Classic RKE function by action up to 6 push buttons.
- Transponder-functionality in case of a flat battery or a disturbed communication.
- LED for operation feedback and battery monitoring.

NOTICE

The FOB's LED indicator may continue to light even with a low transmitter battery.
If the performance or range of the FOB is less than expected, check the transmitter battery.

Antennas

1. Emitting LF Antennas:

Inductive antennas in and at the vehicle are used to transform the current, driven by the SMK ECU antenna driver, into a 125 kHz magnetic field, which is the carrier for the SMART KEY challenge.

Three antennas cover the vehicle's exterior: two antennas in the Door Handles (DS and PS) cover the area around the doors; one antenna in the rear bumper covers the area around the trunk/tailgate.

Two antennas cover the vehicle's exterior: two antennas in the Door Handles (DS and PS) cover the area around the doors.

Up to three antennas cover the vehicle's interior and the trunk interior: two in the passenger compartment and one in the trunk.

2. Bidirectional Immobilizer Antenna (for Limp Home):

The Immobilizer Backup Antenna is used for sending and receiving data: it emits a magnetic field (125 - 135 kHz challenge) and receives changes in the field strength (response of Transponder).

3. External Receiver

The SMART KEY FOB's response is received via the external RF receiver, which is connected to the SMK ECU via a serial communication Line.

The SMK ECU provides a connector pin for the serial communication Line.

Door Handle

The front door handles of the two doors (driver door / passenger door) are equipped with emitting LF-antennas to emit the 125 kHz signals. The front door handles are also equipped with a push button.

Push Button

The push button in door handle serves as a trigger to indicate the user's intent to unlock or lock the vehicle.

The push buttons are installed at front doors, integrated into the door handles.

Another button is installed at the trunk lid.

Operation

Passive Functions

The system allows the user to access the vehicle without having to perform any actions (e.g. RKE button pressing) with the SMART KEY FOB. It is sufficient that a valid SMART KEY FOB is located within a defined and limited range with respect to the vehicle. So the system is capable of detecting and authenticating a SMART KEY FOB in the ranges as specified below.

Operating Range

The SMART KEY FOB receives and interprets a challenge sent from the vehicle via the exterior antennas in a free space

range of min. 0.7m measured around the exterior antennas which are integrated in the door handles; refer to the below given picture. The trunk access range is also min. 0.7m measured from the antenna position. The SMART KEY FOB receives and interprets a challenge sent from the vehicle via the exterior antennas in a free space range of min. 0.7m measured around the exterior antennas which are integrated in the door handles; refer to the below given picture

Passive Access (Passive Entry)

Pressing one of the push buttons in the door handles when all doors locked indicates the operator's intent to access the vehicle and thus triggers the system for unlock

Passive Locking (Exit)

Pressing one of the push buttons in the door handles when one of the following condition is fulfilled:

- at least one door is unlocked and two_steps timer is not running or
- two_steps timer is running and one of the push button except Front Left side is triggered

indicates the operator's intent to lock the vehicle and thus triggers the system for a lock.

Passive Open Tailgate

Pressing the Tailgate Lid Switch when tailgate is closed indicates the operator's intent to open the tailgate and thus triggers the system. Subsequently, the SMK ECU sends a LF-challenge to the SMART KEY FOB via the exterior bumper antenna. The SMART KEY FOB answers with a RF-response. If the received response matches the expected answer, SMK ECU sends a "tailgate open" message via the CAN network.

Passive Trunk Warning

Whenever the trunk is closed, SMK ECU uses a suitable search strategy to avoid trunk buzzer warning by a fob outside the vehicle. Then SMK searches for a SMART KEY FOB in the interior of the trunk. If a valid SMART KEY FOB is found in the trunk, the SMK ECU activates SMK external buzzer (TBD) to inform the user that the trunk has been closed with a fob inside the trunk.

SMK will send the trunk open command to BCM for trunk reopening if Trunk reopening bit is set(BK)For this functionality, a "valid" SMART KEY FOB means any SMART KEY FOB that belongs to the vehicle, even if it's DEACTIVATED.

NOTICE

- A blind spot in the trunk similar to any RF disturbance may lead to no trunk warning. Due to the penetration of the bumper antenna into the trunk area the lid may open without an Identification Device outside.
- A blind spot in the trunk similar to any RF disturbance may lead to no trunk warning

Smart Key Reminder 1

1. Preconditions:

All terminals OFF & at least one door open & locking status is not locked checked by SMK periodically every 100ms, as long as CAN/LIN active.

2. Event:

At least 1 door knob status changed from unlock to lock.

3. SMK actions:

A. IF NO FOB-IN ACTIVE

SMK performs a search for the fobs in the interior of the vehicle. The same LF-strategy has to be used as it is defined for the ID out warning (registering only, no authentication)

B. IF FOB-IN ACTIVE

SMK sends request toward PDM to search valid TP

If no fob or no TP has been found, no action is required.

If any valid fob or valid TP has been found, SMK unlocks the vehicle by sending a CAN Key Reminder unlock message with the fob number.

If any valid fob has been found, SMK unlocks the vehicle by sending a CAN/LIN Key Reminder unlock message with the fob number.

Smart Key Reminder 2

1. Preconditions:
All terminals OFF & any door (including tail gate) open & no FOB-IN & no locking status (checked by SMK periodically every 100ms, as long as CAN/LIN active)
2. Vehicle action:
Closing last door or tail gate with knobs locked state, or with a locking in progress
3. SMK actions:
Before elapsing 500ms after the closing if all doors are locked then:
 - A. IF NO FOB-IN ACTIVE
SMK performs a search for the fobs in the interior of the vehicle.
The same LF-strategy has to be used as it is defined for the ID out warning (registering only, no authentication)
 - B. IF FOB-IN ACTIVE
SMK sends request toward PDM to search valid TP
If no fob has been found, no action is required.
If any valid fob or valid TP has been found, SMK sends unlock command via CAN and activates ext. buzzer warning.
If any valid fob has been found, SMK sends unlock command via CAN/LIN and activates ext. buzzer warning.

Smart Key Door Lock Warning**Door Lock Warning 1**

1. Preconditions:
While (at least one door knob is unlocked) & (ACC ON or IGN ON) & (No FOB-IN) :
A. (All doors are closed) & (tailgate closed)
2. Event:
A. User presses the push button in door handle or tailgate
3. SMK actions:
SMK performs a search for the fobs outside of the vehicle; the same LF-strategy has to be used as it is defined for "Scenario Access with I/O Distinction".

Door Lock Warning 2

1. Preconditions:
Same as passive locking precondition but with at least one door open.
2. Event:
User presses the door handle Push button .
3. SMK actions:
SMK performs a search for the fobs outside of the vehicle; the same LF-strategy has to be used as it is defined for "Scenario Access with I/O Distinction".
If no fob has been found, no action is required.
If the preconditions are no longer valid during buzzer active time (3 seconds), the SMK ECU stops the buzzer immediately.

Door Lock Warning 3

1. Preconditions:
Same as passive locking precondition
2. User action:
A. User presses the door handle Push button
3. SMK ECU actions:
A. If ATWS(Anti Theft Warning System) is in DISARM status, SMK ECU performs a search for the fob inside of the vehicle (use "Door Lock Warning 3" scenario)
If no fob has been found, the passive locking is performed.

If any valid fob has been found, SMK ECU activates the external buzzer.

If the activity timer elapsed or ACC ON or IGN1 ON or NOT All door closed or FOB-IN, the SMK ECU stops the buzzer immediately.

After searching of inside fob, SMK ECU also performs a search for fobs outside of the vehicle.

Smart Key Lamp Warning

1. SMK actions:

As long as the preconditions are valid, the SMK ECU performs a periodical search for the fobs in the interior of the vehicle; the same LF-strategy has to be used as it is defined for the ID out warning (registering only, no authentication); periodical means, the search is done every 3 seconds.

If no fob has been found, the SMK ECU starts Key out indicator lamp activation as all preconditions are valid and will perform another search 3 seconds later.

If any valid fob has been found, the SMK ECU stops the Key out indicator lamp and will (if one door is open) perform another search 3 seconds later; if no door is open then it's only at the next When the preconditions are still valid, the search resumes by opening of one door.

Failsafe Functions (Backup For Limp Home)

In case of a discharged battery of the SMART KEY FOB or disturbed transmission, the following functions are available:

- Unlocking / locking of doors or trunk (or tailgate depending of the vehicle configuration): use of mechanical key

User Information Functions

ID OUT Warning

1. Preconditions:

- A. (ACC or IGN1) & (any door open or tailgate open)

2. Event:

The last opened door is closed

3. SMK action:

SMK searches for a SMART KEY FOB in the interior.

- A. If no valid SMART KEY FOB is found, the SMK activates external buzzer and also sends ID OUT WNG via CAN (exterior buzzer warning and internal buzzer warning).
- B. If a door is opened and closed again during terminals on and inside valid fob, SMK re-enables the authentication and stops the warning. If the terminal is in ACC, SMK shall turn on immobilizer lamp.

NOTICE

If there is a LF error (LF overheating or LF antenna failure), the system will have the same behavior as it is with no fob found.

Immobilizer Lamp

Removing the PIF from the MSL and reinserting the PIF and pushing the MSL Knob will switch the lamp on again.

Fob Battery Low Voltage Detection

To detect fob low battery condition, certain battery voltage measurement and low voltage detection strategy are implemented into fob. The measurement of the battery voltage will be done if fob button is pressed or if a LF measurement command is received.

If the fob has detected a low battery voltage, the LED will not be switched on at button press.

Learning Description

In this chapter, the learning procedure for SMK, PDM, ESCL and FOBs is described.

For the learning of the SMK, PDM, ESCL and FOBs, it's necessary to have a connection to the diagnostic tool.

Learning MODE

Whatever the mode, the learning procedures are managed by the SMK.

Prior to start learning service, Fob-In signal must be active and the vehicle secret code (called as PIN code) should be known.

Teaching MODE


This mode is used by the dealers in order to replace SMK and/or PDM and/or ESCL and/or the set of keys, or to register additional keys for an existing system. That means the system already has been learnt with certain PIN Code. The PIN Code is fixed for the life time of the vehicle, therefore the same PIN Code must be used in this mode. Otherwise learning will be failed

Teaching MODE Procedure Description (Step By Step)

Objective: Key teaching procedure at service station

Initial state:


- SMK replacement: SMK is not learnt, PDM and ESCL and SMART FOB are already learnt with same PIN code
- PDM replacement: PDM is not learnt, SMK and ESCL and SMART FOB are already learnt with same PIN code
- ESCL replacement: ESCL is not learnt, SMK and PDM and SMART FOB are already learnt with same PIN code
- Additional or new keys teaching: SMK and PDM and ESCL are already learnt with same PIN code



Starting After Replacing (Virgin Start)

Starting is possible by following process after replacing new smart key unit , PDM, FOB key or ESCL.

- It is for starting at virgin condition
- All related parts are virgin condition (Smart key, IPM, PDM, ESCL ECM)
- ESCL is always unlock at virgin
- When virgin smart key is inserted in smart key holder, possible to start, IG ON and ACC position
- Press brake pedal in P or N range
- After inserting virgin smart key to holder, push start button once.



www.cargeek.ir

Inspection

Self Diagnosis With Scan Tool

Smart key system defects can be quickly diagnosed with the GDS. GDS operates actuator quickly to monitor, input/output value and self diagnosis.

The following three features will be major problem in SMART KEY system.


1. Problem in SMART KEY unit input.
2. Problem in SMART KEY unit.
3. Problem in SMART KEY unit output.

The following three diagnostic solutions will be the main solution process to a majority of concerns.

1. SMART KEY unit Input problem : switch diagnosis
2. SMART KEY unit problem : communication diagnosis
3. SMART KEY unit Output problem : antenna and switch output diagnosis

Switch Diagnosis

1. Connect the cable of scan tool to the data link connector in driver side crash pad lower panel, turn the power on scan tool.
2. Select the vehicle model and then SMART KEY system.
3. Select the "SMART KEY unit".
4. After IG ON, select the "Current data".



5. You can see the situation of each switch on scanner after connecting the "current data" process.

Display	Description
FL Toggle SW	ON : Push button is ON in the driver door handle.
FR Toggle SW	ON : Push button is ON in the assist door handle.
Trunk/tail Gate SW	ON : Tailgate button is ON.
Gear P Position	ON : Shift lever is P position.
IGN 1	ON : IGN switch is IG position.
ACC	ON : IGN switch is ACC position.
Push Knob SW	ON : Push knob switch is ON.
External Buzzer	ON : Buzzer is ON.

Communication Diagnosis With Scan Tool (Self Diagnosis)

1. Communication diagnosis checks that the each linked components operates normal.
2. Connect the cable of scan tool to the data link connector in driver side crash pad lower panel.
3. After IG ON, select the "SELF DIAGNOSIS".

KIA 1. VEHICLE DIAGNOSIS	
MODE : TD	
SYSTEM : SMART KEY SYSTEM	
SPECIFICATION : SMART KEY UNIT	
01. DIAGNOSTIC TROUBLE CODES	
02. CURRENT DATA	
03. FLIGHT RECORD	
04. ACTUATION TEST	
05. SIMU-SCAN	
06. IDENTIFICATION CHECK	
07. STATUS CHECK	
08. FOB STATUS INFORMATION	

1.1 DIAGNOSTIC TROUBLE CODES	
CANERROR	
CAN BUS ERROR	
NUMBER OF DTC : 2	
ERAS	HELP

Antenna Actuation Diagnosis

1. Connect the cable of scan tool to the data link connector in driver side crash pad lower panel.
2. After IG ON, select the "ACTUATION TEST".

KIA 1. VEHICLE DIAGNOSIS	
MODE : TD	
SYSTEM : SMART KEY SYSTEM	
SPECIFICATION : SMART KEY UNIT	
01. DIAGNOSTIC TROUBLE CODES	
02. CURRENT DATA	
03. FLIGHT RECORD	
04. ACTUATION TEST	
05. SIMU-SCAN	
06. IDENTIFICATION CHECK	
07. STATUS CHECK	
08. FOB STATUS INFORMATION	

3. Set the smart key near the related antenna and operate it with a scanner.

ACTUATION TEST		4/9
INTERIOR ANTENNA 1 ACTIVE		
DURATING	UNTIL STOP KEY	
METHOD	ACTIVATION	
CONDITION	IG. KEY ON, ENGINE OFF	
PRESS [STRT]. IF YOU ARE READY ! SELECT TEST ITEM USING UP/DOWN KEY		
[STRT] [STOP]		

4. If the LED of smart key is blinking, the smart key is normal.
5. If the LED of smart key is not blinking, check the voltage of smart key battery.
6. Antenna actuation
 - A. INTERIOR Antenna 1
 - B. INTERIOR Antenna 2
 - C. INTERIOR Antenna 3
 - D. BUMPER/ TAIL GATE Antenna
 - E. DRV_DR Antenna
 - F. AST_DR Antenna

Antenna Status Check

1. Connect the cable of scan tool to the data link connector in driver side crash pad lower panel.
2. Select the "07.Status Check".
3. After IG ON, select the "03.Antenna Status Check".

KIA 1. VEHICLE DIAGNOSIS
MODE : TD
SYSTEM : SMART KEY SYSTEM
SPECIFICATION : SMART KEY UNIT
01. DIAGNOSTIC TROUBLE CODES
02. CURRENT DATA
03. FLIGHT RECORD
04. ACTUATION TEST
05. SIMU-SCAN
06. IDENTIFICATION CHECK
07. STATUS CHECK
08. FOB STATUS INFORMATION

4. Set the smart key near the related antenna and operate it with a scanner.

ANTENNA STATUS CHECK
MODEL : TD
SYSTEM : SMART KEY SYSTEM
Q1. INTERIOR ANTENNA 1
Q2. INTERIOR ANTENNA 2
Q3. INTERIOR ANTENNA 3
Q4. BUMPER/TAIL GATE ANTENNA
Q5. DRV-DR ANTENNA
Q6. AST-DR ANTENNA

ANTENNA STATUS CHECK
MODEL : TD
SYSTEM : SMART KEY SYSTEM
BRING A FOB KEY CLOSE TO BUMPER/TAIL GATE ANTENNA AND PRESS [ENTER]


5. If the smart key runs normal , the related antenna, smart key(transmission, reception)and exterior receiver are normal.
6. Antenna status
 - A. INTERIOR Antenna 1
 - B. INTERIOR Antenna 2
 - C. INTERIOR Antenna 3
 - D. BUMPER/ TAIL GATE Antenna
 - E. DRV_DR Antenna
 - F. AST_DR Antenna

Serial Communication Status Check

1. Connect the cable of scan tool to the data link connector in driver side crash pad lower panel.
2. Select the "Status Check".

ANTENNA STATUS CHECK
MODEL : TD
SYSTEM : SMART KEY SYSTEM
Q1. DIAGNOSTIC TROUBLE CODES
Q2. CURRENT DATA
Q3. FLIGHT RECORD
Q4. ACTUATION TEST
Q5. SIMU-SCAN
Q6. IDENTIFICATION CHECK
Q7. STATUS CHECK
Q8. FOB STATUS INFORMATI


3. After IG ON, select the "SRx COMM. LINE Status Check".




4. Check the serial communication line with a scanner.
5. If the smart key runs normal, the communication of smart key unit, exterior receiver and MSL(Mechatronic Steering column Lock) are normal.
6. If the smart key runs abnormal, check the following items.
 - A. Disconnection or no response of the exterior receiver communication line.
 - B. The exterior receiver communication line disconnection and ground connection.
 - C. The MSL disconnection or no response
 - D. The MSL disconnection and ground connection

Interior Antenna Actuation Check


1. Set the smart key in the following shade area and check the IG ON.




2. If the ignition is ON, the antenna runs normal.
3. Check the interior antenna ignition mode.
4. Set the smart key in the following shade area and actuate the antenna. Check the LED of smart key is blinking.



5. If the LED of smart key is not blinking, check the antenna in shade area.



Components



Connector Pin Information

Pin	Connector A	Pin	Connector B
1	BAT	1	Interior 2 antenna 2
2	IMMO Indicator	2	Interior 1 antenna 2
3	GND 1	3	-
4	-	4	Interior 4 antenna 2
5	Trunk lid	5	Trunk 1 antenna 1
6	Front left door lock / unlock	6	Bumper antenna 1
7	Buzzer	7	RH door antenna 1
8	ALT L	8	LH door antenna 1
9	ACC	9	Interior 2 antenna 1

10	CAN high	10	Interior 1 antenna 1
11	CAN low	11	-
12	ESCL COM	12	Interior 4 antenna 1
13	RF COM	13	Trunk 1 antenna 2
14	IGN 1	14	Bumper antenna 2
15	P position	15	RH door antenna 2
16	GND 2	16	LH door antenna 2
17	Key out IND		
18	ESCL Enable		
19	Push Knob		
20	Front right door lock / unlock		
21	-		
22	Diagnosis		
23	SSB switch 2		
24	Brake		
25	EMS COM		
26	LIN COM		

Inspection

Smart Key Unit

- Refer to the BE group - inspection / self diagnosis with scan tool.

Smart Key Switch


- Refer to the BE group - inspection / self diagnosis with scan tool.

Antenna

- Refer to the BE group - inspection / self diagnosis with scan tool.

Trunk Lid Open Switch

1. Remove the trunk trim.
(Refer to BD group - "Trunk trim")
2. Check for continuity between the Trunk actuator terminals.





3. If continuity is not specified, inspect the switch

Terminal Position	1	3
Unlock		
Lock	○	○


Removal

Smart key unit

1. Disconnect the negative(-) battery terminal.
2. Open the trunk and remove the right side trim (A).
(Refer to BD group - "Trunk")



3. Loosen the nuts(2EA) from the smart key unit(A) after disconnecting the connector.




RF Receiver


1. Disconnect the negative(-) battery terminal.
2. Remove the glove box(A).
(Refer to BD group - "Crash pad")



3. Remove the glove box housing(A) after loosening the mounting screws.




4. Disconnect the connector (A) after loosening the RF receiver(C) nuts (B).




Interior 1 Antenna

1. Disconnect the negative(-) battery terminal.
2. Remove the floor console (A).
(Refer to BD group - "Console")




3. Loosen the interior 1 antenna (A) units (2EA) located in front of the console.




Interior 2 Antenna

1. Disconnect the negative(-) battery terminal.
2. Remove the floor console (A).
(Refer to BD group - "Console")




3. Disconnect the interior 2 antenna connector (B) located at the console rear side, then remove the interior 2 antenna (A) after loosening nuts (2EA).




Interior 3 Antenna

1. Disconnect the negative(-) battery terminal.
2. Remove the trunk panel.
3. Disconnect the interior 3 antenna connector(A) and remove the interior 3 antenna(B) after loosening nut(2EA).




Exterior Bumper Antenna

1. Disconnect the negative(-) battery terminal.
2. Remove the rear bumper.
(Refer to BD group - "Rear bumper")
3. Disconnect the antenna connector (A) and remove the exterior bumper antenna (B) after loosening the nuts(2EA).




Buzzer

1. Disconnect the negative(-) battery terminal.
2. Remove the left side fender.
(Refer to BD group - "Fender")
3. Remove the external buzzer(A).




Door Outside Handle


1. Disconnect the negative (-) battery terminal.
2. Disconnect the connector after removing the door trim.
(Refer to the Body group - "Front door")



3. After loosening the mounting bolt, then remove the key holder (A).




4. Remove the outside handle (A) by sliding it rearward.




Trunk Lid Switch

1. Disconnect negative(-) battery terminal.
2. Remove the trunk lid trim.
(Refer to the Body group - "Trunk")
3. Remove the trunk garnish (A).



4. Remove the trunk lid switch (A).



Installation

Smart Key Unit

1. Install the smart key unit.
2. Install the smart key unit mounting nuts and connector.
3. Install the right side trim in the trunk.

4. Install the negative (-) battery terminal and check the smart key system.

RF Receiver

1. Install the RF receiver.
2. Install the glove box housing.
3. Install the glove box.
4. Install the negative (-) battery terminal and check the smart key system.

Interior 1 Antenna

1. Install the interior 1 antenna.
2. Install the floor console.
3. Install the negative (-) battery terminal and check the smart key system.

Interior 2 Antenna

1. Install the interior 2 antenna.
2. Install the floor console.
3. Install the negative (-) battery terminal and check the smart key system.

Interior 3 Antenna

1. Install the interior 3 antenna.
2. Install the trunk panel.
3. Install the negative (-) battery terminal and check the smart key system.

Exterior Bumper Antenna

1. Install the exterior bumper antenna.
2. Install the rear bumper.
3. Install the negative (-) battery terminal and check the smart key system.

Buzzer

1. Install the buzzer.
2. Install the left side fender.
3. Install the negative (-) battery terminal and check the smart key system.

Door Outside Handle

1. Install the outside handle.
2. Install the door trim.
3. Install the negative (-) battery terminal and check the smart key system.


Trunk Lid Switch

1. Install the trunk lid switch.
2. Install the trunk garnish.
3. Install the trunk lid trim.
4. Install the negative (-) battery terminal and check the smart key system.


Smart Key

Smart Key Code Saving


1. Connect the DLC cable of scan tool to the data link connector (16 pins) in driver side crash pad lower panel, turn the power on scan tool.



2. Select the vehicle model and then do "Smart key code saving".



3. After selecting "Smart key teaching" menu, push "Enter" key, then the screen will be shown as below.



4. After inserting the teaching key, push "ENTER" key.
5. Input the "Pin code" for first key teaching.

1. KIA VEHICLE DIAGNOSIS

MODEL : TD
SYSTEM : SMART KEY CODE SAVING
SMK STATUS : LEARN

INPUT PIN OF SIX
AND PRESS [ENTER]

PIN NUM.: _

1. KIA VEHICLE DIAGNOSIS

MODEL : TD
SYSTEM : SMART KEY CODE SAVING
SMK STATUS : LEARN

INPUT PIN OF SIX
AND PRESS [ENTER]

PIN NUM.: 000000_

6. Confirm the message "First key teaching completed".

1. KIA VEHICLE DIAGNOSIS

MODEL : TD
SYSTEM : SMART KEY CODE SAVING
SMK STATUS : LEARN

1st KEY TEACHING
ARE YOU SURE ? [Y/N]

PIN NUM.: 000000_

7. Input the "Pin code" for second key teaching.

1. KIA VEHICLE DIAGNOSIS

MODEL : TD
SYSTEM : SMART KEY CODE SAVING
SMK STATUS : LEARN

2nd KEY TEACHING
ARE YOU SURE ? [Y/N]

PIN NUM.: 000000_

8. Confirm the message "Second key teaching completed".

1. KIA VEHICLE DIAGNOSIS
MODEL : TD
SYSTEM : SMART KEY CODE SAVING
SMK STATUS : LEARNED
2nd KEY TEACHING COMPLETED
PIN NUM.: 000000

9. Then the screen will be shown as below when key teaching process is completed.

www.cargeek.ir



SAIPA YADAK

DAROU PAKHSH St.-KM17 KARAJ MAKHSOOS ROAD-TEHRAN

www.saipayadak.org