




F1	LOAD OFF RELAY	60A
F2	VACUUM PUMP	30A
F3	KL30-2 TO PJB	60A
F4	EPS	80A
F5	KL30-1 TO PJB	60A
F6	COOLING FAN 1.5T	40A
F7	ABS PUMP	40A
F8	N/A	—
F9	MAIN RELAY	30A
F10	ENGINE ECU-1	10A
F11	STARTER RELAY	30A
F12	FUEL PUMP	15A
F13	ABS VALVE	20A
F14	HORN	15A
F15	A/C COMPRESSOR	10A
F16	SIGNAL	5A
F17	IGNITION	15A
F18	INJECTOR	15A
F19	ENGINE ECU-2	15A
F20	LAMBADA	—

R1	LOAD OFF	70A
R2	COOLING FAN LOW	40A
R3	VACUUM PUMP RELAY	70A
R4	MAIN RELAY	30A
R5	HORN	30A
R6	N/A	—
R7	COOLING FAN HIGH	70A
R8	STARTER	40A
R9	N/A	—
R10	FUEL PUMP	30A
R11	A/C COMPRESSOR	30A